

AKVA BOX

- Assemble the base frame with aluminium corners (1).
- Attach headboard fittings if the bed has a headboard (2).
- Position the stabilisers inside the base frame as shown (3).
- The number of stabilisers varies depending on the width of the bed (4).
- Position the base boards on the base frame and connect them with the four black "legs" (5).
- With headboard: fit the headboard by lowering the openings at the underneath of the headboard to slide on to both fittings (6).

