

# ALLROUND

- Fit the base frame (1). See instructions for Akva bases.
- Fit the wooden frame by attaching the threaded pin approx. 4 mm into the bushing on the underside of the wooden frame. Place the wooden frame on the base boards (2). Fasten the metal heads loosely on the threaded pin (2.1). Join the wooden frames one by one with angle brackets. Fasten the screws, begin with the screws closest to the joint of the corners (2.2). Fasten the screws on the underside of the base boards.
- Fit the bottom of the cover so that the AKVA logo is located at the foot end (3). Remove the top, place the fixing paddles in the holes at the bottom of the cover and secure them by inserting them in the holes in the base board.
- Place the side foam frames in the cover (4), then head and foot end foams (5).
- Place the heating element(s) (6). Feed out the tube under the foam frame, through the hole in the bottom of the cover and the bottom plate as shown on drawing (6.1). See the instructions for Akva Vital Electronic heating elements before assembling them.
- Fit the safety liner (7). The safety liner is supplied in two variants: inliner 9.1 or outliner 9.2.
- If it is a bed with two water mattresses, place the foam or water divider supplied in the centre of the bed after the safety liner is fitted (8).
- Place the water mattress in the safety liner (9). See instructions for water mattresses.
- After filling with water, remove the air and add Long Life (water disinfectant.) Zip the top of the cover to the bottom of the cover (10). See also instructions for cover.

