

## INSIDE

- Fit the base frame (1) and (2). See instructions for Akva bases.
- Fit the foam frame (3) by securing the fastening tape on the foam frame to the fastening tape on the base board. The edge of the foam frame must be aligned to the edge of the base board. Assemble the corners of the foam frame with fastening tape.
- Fit the bottom of the cover so that the AKVA logo is placed at the foot end (4). Remove the top, place the fixing paddles in the holes at the bottom of the cover and secure them by inserting them in the holes in the base board.
- Place the side foam frames in the cover (5), then head and foot end foams (6).
- Place the heating element(s) (7). Feed out the tube under the foam frame, through the hole in the bottom of the cover and the bottom plate as shown on drawing (8). See the instructions for Akva Vital Electronic heating elements before assembling them.
- Fit the safety liner (9). The safety liner is supplied in two variants: inliner 9.1 or outliner 9.2.
- If it is a bed with two mattresses, place the foam or water divider supplied in the centre of the bed after the safety liner is fitted.
- Place the water mattress in the safety liner (11). See instructions for water mattresses.
- After filling with water, remove the air and add Long Life (water disinfectant.) Zip the top of the cover to the bottom of the cover (12). See also instructions for cover.

