

AKVA MIRA WITHOUT HEADBOARD

- Assemble the base, position stabilisers and base boards. See instructions for Akva Box.
- Fit the Mira frame by fastening the angle brackets loosely on the upholstered side pieces. Loosely fit the upholstered foot and head end pieces to the side pieces. Hardware bag no. 3 is to be used above the base boards, bag no. 2 below the base boards. Fasten the corners of the frame one by one. Begin with the screws farthest in.
- When the frame is tightened, it is fastened to the base board with angle brackets in the middle of each upholstered piece (Hardware bag no. 1.)
- Fit the rest of the bed. See instructions for HARDSIDE and INSIDE respectively, beginning from item (3.) When Inside version: the lower foam is only to be placed on the base boards, it is not to be secured with fastening tape.

