

AKVA SOFT / AKVA JUNIOR

- Fit base frame (1) and (2). See instructions for Akva bases.
- Fit the bottom of the cover so that the Akva logo is located at the foot end (3). Remove the top, place the fixing paddles in the holes at the bottom of the cover, secure them by placing them in the holes of the base board.
- Place the side foam frames in the cover (4), then head and foot end foams (5).
- Position the heating element(s) (6). Feed out the tube under the foam frame, through the hole in the bottom of the cover and the bottom plate as shown on drawing (7). See the instructions for the Akva Vital Electronic heating elements before fitting them.
- Fit the safety liner (8). The safety liner is supplied in two variants: inliner (8.1) and outliner (8.2).
- If it is a bed with two water mattresses, place the foam or water divider in the centre (9) after fitting the safety liner.
- Place the water mattress in the safety liner (10). See the instructions for water mattresses.
- After filling with water, remove the air and add Long Life (water disinfectant.) Zip the top of the cover to the bottom of the cover (11). See also instructions for cover.

