

AKVA VEGA

- Assemble the base frame with aluminium corners (1).
- Fit headboard fittings if the bed has a headboard (2).
- Mount the headboard by placing the openings at the bottom of the headboard on the headboard fittings (2).
- If headboard with integrated lamps, secure the lamps from the inside of the headboard (2.1). Remember to connect the power.
- Position the stabilisers inside the base frame. See instructions for Akva Box.
- Position the base boards on the base frame. Assemble the base boards with the four legs (3). See instructions for Akva Box if necessary.
- Assemble the silver lacquered frame with the screws (4.1). Position the frame around the base.
- If bed with headboard, fit the silver lacquered frame for headboard at the head end. If bed without headboard, the silver lacquered frame is identical in head- and foot end (4.2).
- Before assembling the upholstered bed frame, fit the small chromed angle fittings loosely in the pre-drilled holes with the washer (5).
- Position the bed frame on the bottom plate where the bottom plate fits the groove (6). Assemble with angle fittings. Screw the angle fittings loosely in the four corners. After assembling the bed frame, fasten the screws.
- Mount the silver lacquered frame on the bed frame by screwing them on to the small chromed angle fitting (6.1). The angle fitting can be adjusted while fastening the silver lacquered frame.
- Secure the frame to the base plate with angle brackets.
- Fit the bottom of the cover so that the Akva logo is placed at the foot end (7). Remove the top, place the fixing paddles in the holes at the bottom of the cover; secure the cover by placing the paddles in the holes of the bottom plate.
- Place the side foam frames in the cover (8), then head and foot end foams (9).
- Place the heating element(s) (10). Feed out the tube under the foam frame and through the hole in the bottom of the cover and the bottom plate as shown on the drawing. See instructions for Akva Vital Electronic heating elements before assembling them.
- Fit the safety liner (11).
- If it is a bed with two water mattresses, place the foam or water divider supplied in the centre of the bed (11) after fitting the safety liner.
- Place the water mattress in the safety liner (12). See instructions for water mattresses.
- After filling with water, remove the air and add Long Life (water disinfectant.) Zip the top of the cover to the bottom of the cover (13). See also instructions for cover.

